

# LIFT-U<sup>®</sup>

A DIVISION OF HOGAN MFG., INC.



---

## ACCESSOR III PREVENTATIVE MAINTENANCE SCHEDULE

---

					<i>Accessor III LIFT</i>
					<b>PREVENTIVE MAINTENANCE SCHEDULE</b>
WEEKLY	6 WEEKS	6 MONTHS	OTHER	MANUAL SECTION REF.	ITEM DESCRIPTION (manual sectional references where applicable)
X					<b>CYCLE LIFT</b>
		X		<b>VISUAL</b>	<b>INSPECT ELECTRIC POWER SOURCE:</b> A – MOUNTING BOLTS.
		X		<b>VISUAL</b>	B – ELECTRICAL CONNECTIONS
		X		<b>VISUAL</b>	<b>INSPECT MACHINE SCREW JACKS</b> A – STRUCTURAL INTERGRITY OF MACHINE SCREW JACKS
		X		<b>VISUAL</b>	B – MOUNTING BOLTS
	X			<b>S3 - 1</b>	G – LUBRICATION I –MACHINE SCREW JACK COLUMN (LUBE WITH ACME SCREW LUBRICANT)
	X			<b>VISUAL</b>	<b>INSPECT LIMIT SWITCHES:</b> A – DAMAGE TO LIMIT SWITCH LEVEL ARM
	X			<b>VISUAL</b>	B – ALIGNMENT OF LIMIT SWITCH LEVER ARM TO TARGET
				<b>VISUAL</b>	<b>INSPECT DRIVE MOTOR:</b> A – MOUNTING BOLTS
				<b>VISUAL</b>	B – DRIVE MOTOR PLATE’S MOUNT TO BASE CHANNEL WELDMENT
				<b>VISUAL</b>	C – INTEGRITY OF COUPLING HALVES CONNECTING MOTOR TO GEAR BOX
		X		<b>VISUAL</b>	<b>INSPECT BEARINGS AND GEAR BOXES:</b> A – STRUCTURAL INTERGRITY OF BEARINGS AND GEAR BOXES
		X		<b>VISUAL</b>	B – MOUNTING BOLTS
	X			<b>VISUAL</b>	<b>INSPECT DOOR: (INCLUDING DUTCH DOOR/STEP)</b> A – STRUCTURAL INTERGRITY OF DOOR
	X			<b>VISUAL</b>	B – HINGE AND LATCHING POINT FOR WEAR
	X			<b>VISUAL</b>	C – AUTOMATIC DOOR ACTUATOR ATTACHMENT BOLTS (NOT EQUIPPED ON ALL MODELS)
		X		<b>VISUAL</b>	<b>INSPECT HINGED RISER CLOSEOUT: (NOT EQUIPPED ON ALL MODELS)</b> A – RUST / CORROSION
		X		<b>VISUAL</b>	B – BINDING
		X		<b>VISUAL</b>	C – DAMAGE
		X		<b>S2 – 8</b>	<b>MANUAL OPERATION OF LIFT:</b> A – LIFT UP
		X		<b>S2 – 8</b>	B – LIFT DOWN
		X		<b>S3 – 2</b>	<b>INSPECT LIFT MOUNTING BOLTS – REFERENCE BUILDING CODE TORQUE SPECIFICATIONS</b>
		X		<b>S3 – 2</b>	<b>INSPECT ALL FASTENERS FOR TORQUE</b>
	X			<b>VISUAL</b>	<b>INSPECT FOR “OPERATING PROCEDURE DECAL”</b>