

LIFT-U[®]

A DIVISION OF HOGAN MFG., INC.



ACCESSOR I PREVENTATIVE MAINTENANCE SCHEDULE

WEEKLY	6 WEEKS	6 MONTHS	OTHER	MANUAL SECTION REF.	<i>Accessor I LIFT</i> PREVENTIVE MAINTENANCE SCHEDULE
					ITEM DESCRIPTION (manual sectional references where applicable)
X					CYCLE LIFT
		X X		VISUAL VISUAL	INSPECT ELECTRIC POWER SOURCE: A – MOUNTING BOLTS. B – ELECTRICAL CONNECTIONS
	X	X X		VISUAL VISUAL S3 - 1	INSPECT MACHINE SCREW JACKS A – STRUCTURAL INTERGRITY OF MACHINE SCREW JACKS B – MOUNTING BOLTS G – LUBRICATION I – MACHINE SCREW JACK COLUMN (LUBE WITH ACME SCREW LUBRICANT)
	X X			VISUAL VISUAL	INSPECT LIMIT SWITCHES: A – DAMAGE TO LIMIT SWITCH LEVEL ARM B – ALIGNMENT OF LIMIT SWITCH LEVER ARM TO TARGET
				VISUAL VISUAL VISUAL	INSPECT DRIVE MOTOR: A – MOUNTING BOLTS B – DRIVE MOTOR PLATE'S MOUNT TO BASE CHANNEL WELDMENT C – INTEGRITY OF COUPLING HALVES CONNECTING MOTOR TO GEAR BOX
		X X		VISUAL VISUAL	INSPECT BEARINGS AND GEAR BOXES: A – STRUCTURAL INTERGRITY OF BEARINGS AND GEAR BOXES B – MOUNTING BOLTS
	X X X			VISUAL VISUAL VISUAL	INSPECT DOOR: (INCLUDING DUTCH DOOR/STEP) A – STRUCTURAL INTERGRITY OF DOOR B – HINGE AND LATCHING POINT FOR WEAR C – AUTOMATIC DOOR ACTUATOR ATTACHMENT BOLTS (NOT EQUIPPED ON ALL MODELS)
		X X X		VISUAL VISUAL VISUAL	INSPECT HINGED RISER CLOSEOUT: (NOT EQUIPPED ON ALL MODELS) A – RUST / CORROSION B – BINDING C – DAMAGE
		X X		S2 – 8 S2 – 8	MANUAL OPERATION OF LIFT: A – LIFT UP B – LIFT DOWN
		X		S3 – 2	INSPECT LIFT MOUNTING BOLTS – REFERENCE BUILDING CODE TORQUE SPECIFICATIONS
		X		S3 – 2	INSPECT ALL FASTENERS FOR TORQUE
	X			VISUAL	INSPECT FOR “OPERATING PROCEDURE DECAL”